



cable.internet.phone

319.298.6484
www.ImOn.net

ImOn Communications
625 First Street SE, Suite 520
Cedar Rapids, IA 52401



Program Guide
Digital Video Recorder (DVR)
Reference Guide



R.002.012612

ImOn Communications
319.298.6484
www.ImOn.net

ImOn Program Guide

Find a Program to Watch



Press **Guide** . The Program Guide appears.

Press the **Directional Keys** to move through the program listings and highlight the program you want to watch.

Press **Select** . If the program is currently on, the Program Guide closes and the program you selected appears in full-screen TV. If the program is on in the future, a future program option screen appears.

Search for a Program by Channel, Title, or Theme

Press **Guide** . The Program Guide appears.

Press **Browse By** . The Browse By area of the Program Guide displays the options Title, Channel, and Theme

Press **Move Up** or **Move Down** to highlight one of the following options:

- **Channel:** lists programs numerically by channel number
- **Title:** lists programs alphabetically by program title
- **Theme:** lists programs by theme, such as adventure, comedy, sports, or news

Press **Select** . The Browse By area of the Program Guide displays the programs according to the option you selected.

Search for a Program by Date

Press **Guide** . The Program Guide appears.

Press **Date** . The Browse By area of the Program Guide displays the next 7 dates.

Press **Move Up** or **Move Down** to highlight a date.

Press **Select** . The Program Guide displays the programs that will be broadcast on that date.



ImOn Digital Video Recorder (DVR)

Controlling Live TV



Use the following remote control keys to control a live program in the Main screen –

- PAUSE
- PLAY
- REWIND
- INSTANT REPLAY
- FAST-FORWARD
- LIVE

For example, when you are watching your favorite live TV program and the telephone rings, press PAUSE to pause the program for up to 1 hour and press PLAY to resume the normal play mode.

While in play mode, press REWIND or FAST-FORWARD to reverse or advance the program.

To replay the last 8 seconds of a live or recorded program, press INSTANT REPLAY.


If you have rewound or paused a live program, press LIVE at any time to catch up to the live TV program.


Recording TV Programs

Record a TV Program You Are Watching



Press **Record** .

While in the **Confirm Recording** screen, choose your recording options and press . The Record Indicator is now lit on the front panel of the DVR.


To manually stop recording before the scheduled time, press **Stop**  and then follow the on-screen choices.

Record a TV Program from the Program Guide



Press **Guide** .

Press the **Directional Keys**  to highlight a TV program, and then press **Record** .

In the **Confirm Recording** screen, choose your recording options and press . The recording program is highlighted in red in the Program Guide.


With ImOn DVR, you have the ability to watch one show on TV while recording another or record two shows at the same time.


Record Multiple Episodes of a TV Program




If you want to record all the episodes of a program follow these steps:

Press **Guide** .

Press the arrow keys to highlight the TV program, and then press **Record** .

Choose **All Episodes**. Notice the information in the fourth column changes, based on your selection. Press . If you selected **All Episodes** from the third column, the **All Episode Recording Options** screen appears.

Choose one of the options on the screen.

Press **Select**  to save your settings.


Watching Your Recordings

Access and Play Back Your Recorded Programs Anytime



Press **List** .

Press **Move Up**  or **Move Down**  to highlight the recording you want to watch.

Press **Select**  to display your options.

Managing Recording Space

How Much Recording Space Do I Have?



Press **List** .

Press **B** to display the Preferences screen, which displays the percentage total of space used.